



DES-CONTROLLER		M-03-K-UK	
Application area: all processes with disinfection	Page	1 of 1	
	Date:	060828	
	WVS version	V02	
EXTERNAL PROCEDURE CCD			
Requirements: DES-controller with test-bacteria: <i>Enterococcus faecium</i>			
Procedure: <ul style="list-style-type: none">- use the DES-controller within approx. 1 week after delivery (the shelf life is limited)- put the controller in a washing-glove or something equivalent- never damage the controller- avoid any stagnation during the process- remove the DES-controller immediately from the load after the process- don't tumble dry or calander the controller- rinse the controller with tap-water and let it dry in the air <p>Record the required information on the supplied form.</p> <p>When the DES-controller is dry, return it immediately. Use this address:</p> <p style="text-align: center;">CCD bv., P.O. Box 722, NL-2600 AS DELFT, THE NETHERLANDS</p>			
Remarks: We will send you the results as soon as possible. When handling has not taken place according to the correct procedure, the controller is not analysed because the results will not be reliable.			